



lpmorgan

# LP Morgan Rondo



**HERMA**  
Projection Screen Technology

## User's Manual



### LP Morgan Rondo Deluxe Pull Down

- Installation Instructions
- Screen Care
- Warranty

Herma Projection Screen Technology

Installer: Please leave this manual with the owner

# Table of Contents

|                          |   |
|--------------------------|---|
| To the Owner:            | 1 |
| Mechanical Installation: | 2 |
| Wall:                    | 2 |
| Ceiling:                 | 2 |
| Recessed:                | 2 |
| Screen Use               | 3 |
| Screen Care:             | 8 |
| Warranty:                | 9 |

# To The Owner

Congratulations on purchasing an LP Morgan Projection Screen. This cinema quality screen uses the finest optical and mechanical components to give you maximum enjoyment and a truly cinematic experience.

Please take a moment to review this manual, it will ensure many years of trouble-free service for your new LP Morgan screen.

## Unpacking the screen.

When unpacking the screen, please handle all parts with care. Your LP Morgan Rondo screen comes with the following:

- 1 Screen Case
- 2 Wall mount brackets (3 for screens over 2 metres wide)
- 2 Ceiling mount brackets (3 for screens over 2 metres wide)
- 1 Pull down rod
- 1 User's Manual

# Mechanical Installation


## Wall Installation:

The aluminium brackets should be fixed to the rear wall using fasteners that are appropriate to the wall type.



1. Ensure that the brackets are perfectly level and spaced correctly. The unique extrusion on the back of your screen will allow the brackets to be placed anywhere along its length. To make sure the brackets are correctly spaced they should be as far apart as possible (minimum 900mm) but no further apart than the total screen width.
2. Once the brackets are in place, hook the top back corner of the screen casing over the bracket and pivot the bottom back corner in. The screen is now securely in place and will not come off unless the bottom back edge is pulled away from the wall first.

## Ceiling / Overhead Installation:



1. Ensure that the brackets are perfectly level and spaced correctly. The unique extrusion on the back of your screen will allow the brackets to be placed anywhere along its length. To make sure the brackets are correctly spaced, they should be as far apart as possible (minimum 900mm) but no further apart than the total screen length.
2. Once the brackets are in place, hook the top back corner of the screen casing over the bracket and pivot the bottom back corner in. The screen is now securely in place, and will not come off unless the bottom back edge is pulled away from the wall first.

## Above Ceiling or Concealed Installation:

Herma recommends using the LP Morgan Rondo HideAway to mount your screen above the ceiling. Please refer to separate mounting instructions for installing the HideAway. If pelmet mounting, please ensure that there is enough clearance so, should the screen need to be removed or relocated, there is no need to also remove any pelmets or trim.

## Screen Use

The screen mechanism has been specially designed for ease of use and to maximise the life of the screen. We recommend you follow these simple instructions to ensure you many years of continued visual enjoyment from your LP Morgan screen.

### Lowering the screen:

- Using the pull down ring, lower the screen with a gentle even action. If out of reach, use the pull down rod supplied.
- NEVER lower the screen past the STOP stickers. This could cause damage to the screen surface and the mechanism.

### Raising the screen:

- Again using the pull down ring, give a quick, short tug down to release the mechanism. The screen will automatically retract.
- The LP Morgan *Deluxe* Pull Down features a unique inertia braking device and stopping mechanism to ensure the screen slows down and stops at a predetermined position to further simplify use and increase the life of the screen

### Setting the Upper Stopping Limit:

- You may wish to lower or raise the stopping limit of the deluxe pull down screen to suit your installation requirements.
- Begin with the screen in its retracted position
- Remove the front cover
- Turn screw on right hand side of roller - anticlockwise to lower the limit, clockwise to raise it. While turning the screw, the screen will move to the desired stopping position.
- Replace the front cover.

## Screen Care

### Maintaining a clean screen surface

Your cinema quality optical viewing surface is delicate. Great care is taken to ensure your screen leaves the factory free from foreign particles and is perfectly flat. It is important that you keep the screen surface clean at all times. Any foreign particles can cause repetitive indentations on the screen. It is your responsibility to keep the surface free from grit or foreign matter which could cause damage to the surface.

- A soft cloth or brush may be used to lightly whisk away any loose dirt or dust particles. Do not use a sharp instrument to remove any particles. Softly brush from the centre to the edges.
- NEVER attempt to use solvents, chemicals or abrasive cleaners on the screen.
- The screen may be cleaned with a mild solution of detergent and water and a sponge or lint free cloth. Rub lightly to remove any stubborn marks, then blot with a damp sponge to absorb excess water. Use a clean sponge with clear water to wash off any detergent residue. Dry the screen with a soft cloth / towel so that the detergent does not have time to dry on the screen.
- Avoid getting any foreign materials on it, as cleaning may prove to be very difficult or even impossible (paint, ink, etc.) Never paint in the vicinity of the screen unless the screen surface is completely protected.

With reasonable care you may expect many years of trouble free use from your LP Morgan screen.

### Cleaning your screen case

- The casing can be cleaned with water and a mild detergent and a soft cloth to wash off any marks. Rinse and dry with a clean cloth or towel.

# Warranty Information

## All LP Morgan products are warranted by Herma.

*Customers must fill out the online warranty form, or the warranty card included with the product and post it back to Herma at the reply paid address shown on the back cover in order to qualify for the manufacturer's warranty.*

[www.herma.com.au/warranty](http://www.herma.com.au/warranty)

*The warranty covers defects in workmanship and materials, provided this product has been installed in a normal environment and maintained according to the written instructions. Herma warrants the product against loss of usefulness, discolouration or deterioration of optical quality within the warranty period as a result of manufacturing or material defects. This warranty applies only within Australia.*

## CONDITIONS –

- Herma will repair or replace, with the least possible delay, any defective equipment. Any equipment replaced pursuant to the terms of this warranty shall be retained by Herma
- All costs related to installation and re-installation of the Herma Projection Screen equipment covered by this warranty are not the responsibility of Herma Projection Screen Technology. Herma will not be responsible for any consequential damages during or following installation procedures.
- The user is responsible for any freight costs relating to repair or replacement. Equipment must be returned to Herma in suitable packing to prevent damage in transit. Herma will not accept any responsibility for damage to the equipment caused by inadequate or unsuitable packing, or for any damage howsoever caused whilst the goods are in transit.

Herma Projection Screen Technology shall not be liable for any injury, loss or damage, direct or consequential, arising out of the use of, misuse of, or inability to use, the equipment.

This Warranty does not cover any equipment which has been subjected to misuse, abuse, neglect, accidental or intentional damage, improper voltage or any alteration which affects the reliability or performance of the equipment not attributable to faulty manufacture, parts or labour and without limiting the generality of the foregoing shall not apply where the defect arose as the result of the following circumstances:

This Warranty does not cover any equipment where usage, adaptation or installation (including wiring of electrical connections) are not in accordance with our written installation and operating instructions.

Warranty Period: Rondo Casing and Roller: 2 years from date of installation not to exceed 27 months from date of invoice.

Screen Surface: 1 year from date of installation not to exceed 15 months from date of invoice.

**Herma Projection Screen Technology**

This LP Morgan Rondo Pull Down Pack Contains:

QTY

1 Pull Down Rod

2 or 3 Wall Brackets

2 or 3 Ceiling Brackets

| Two Brackets   | Three Brackets              |
|----------------|-----------------------------|
| 72V, 84V, 90V  | 100V, 120V, 150V            |
| 82H            | 92H, 100H, 110H, 120H, 140H |
| 1500AV, 1830AV | 2000AV, 2440AV              |

**Warranty Registration**  
Reply Paid 76217  
PRESTON VIC 3072

Your LP Morgan Retailer is able to provide information on your screen. If we can be of any further help, please contact us.

**Physical Address:**  
Factory 4A, 6 Albert Street  
PRESTON, VIC 3072

**Phone:** +61 3 9480 6233

**Fax:** +61 3 9480 6533

**Email:** [info@herma.com.au](mailto:info@herma.com.au)

**Web:** [www.herma.com.au](http://www.herma.com.au)

**Herma Projection Screen Technology**



**HERMA**  
Projection Screen Technology



**lpmorgan**